



# MINIMET


## SkyeLynx Deluxe Live Data View

### Accumulation of Rainfall (or other sensors)

In Live Display mode, the logger can be set up to remain in Log Mode and the display screen refreshed at each logging interval, or it can be put into Option 1 of the Main Menu (not logging) and the display screen refreshed at 5 second intervals.

In the Main Menu Option 1 mode there is also a choice for the PC to store the data coming from the logger (as the logger cannot) so that data is not lost.

The scale of the Rainfall graphic (which can also be assigned to other sensors if appropriate) can be changed by clicking the 'Opts' box, but to a maximum of 999 for this parameter. See example below of accumulating wind speed being displayed.



**SKYE INSTRUMENTS LTD**  
21, Ddole Enterprise Park, Llandrindod Wells, Powys, LD1 6DF, UK  
Tel: +44(0)1597 824811 Fax: +44(0)1597 824812  
Email: [skyeemail@skyeinstruments.com](mailto:skyeemail@skyeinstruments.com) Web: [www.skyeinstruments.com](http://www.skyeinstruments.com)

