

DataHog2 - Changing Date & Time (cont)

3. TO SET THE CLOCK

When the Main Menu is displayed, press 6 and follow instructions, as in the example below. Remember that the format is important, separators are colons in the time entry and full stops in the date entry.

TIME AND DATE SETTING ROUTINE

ENTER TIME AND THEN DATE AS INSTRUCTED
CLOCK STARTS WHEN DATE ENTRY IS CONFIRMED

THIS IS THE CURRENT TIME 16:16:03
ENTER THE NEW TIME 16:17:00

YOU HAVE ENTERED THIS TIME 16:17:00
IS THIS CORRECT?
<Y> TO ACCEPT, <N> TO REDO, <ESC> TO QUIT

Y CONFIRMED

THIS IS THE CURRENT DATE 29.10.98
ENTER THE NEW DATE 29.10.98
YOU HAVE ENTERED THIS DATE 29.10.98
IS THIS CORRECT?
<Y> TO ACCEPT, <N> TO REDO, <ESC> TO QUIT

Y CONFIRMED
CLOCK IS NOW RUNNING

4. Always remember to press ESCAPE when finished, to return the DataHog2 to log mode. Your keypress will be confirmed.

>>> RETURNING TO LOG MODE >>>

Before disconnecting the logger or hanging up the phone call, always make sure that you see the following message appear every 10 seconds, which will confirm that the DataHog is in fact 'asleep' and logging.

<ANY NUMERIC KEY TO WAKE-UP (!0 TO 9!)>
16:18:20 29.10.98
Date and Time