



MINIMET

SkyeLynx Deluxe Problems when entering dates

SkyeLynx Deluxe requires the PC to be set up in British date format (e.g. DD/MM/YYYY) please see separate datasheet for instructions on how to check the set up of your PC.

If, when the PC is set up in the correct date format, you still get a 'run time error' whenever you choose dates using the calendar (in graphing or data summary functions), there may still be some other setting on your PC which is not compatible with SkyeLynx Deluxe.

In such cases, please use the manual date entry option as shown below:

Summary Periods

Starting Date

December 2003 | December | 2003

Sun	Mon	Tue	Wed	Thu	Fri	Sat
30	1	2	3	4	5	6
7	8	9	10	11	12	13
14	15	16	17	18	19	20
21	22	23	24	25	26	27
28	29	30	31	1	2	3
4	5	6	7	8	9	10

Enter date manually - dd/mm/yyyy

Starting date :

OK Cancel

Click to place a tick in the box marked "Enter date manually" and then type in your date in the format shown "dd/mm/yyyy" before clicking OK.

SKYE INSTRUMENTS LTD
21, Ddole Enterprise Park, Llandrindod Wells, Powys, LD1 6DF, UK
Tel: +44(0)1597 824811 Fax: +44(0)1597 824812
Email: skyeemail@skyeinstruments.com Web: www.skyeinstruments.com

