



MINIMET

To Change the Graph X Axis labels

1. Create the graph as usual
2. Right click the mouse button on the main graph screen area to reveal the 2D Chart Control Properties window
3. Click on the AXES tab, highlight X to choose the x axis and then click on the ANNOTATION tab
4. The 'Anno. Meth.' Box should show Value Labels. There is a small button to the right of this with 3 dots in it. Click this button.
5. SkyeLynx Deluxe defaults to just 5 X axis labels, equally spread along the axis. You may add to or delete from this default number as you wish.
For example, to add a label for every day in a 1 week graph from 1st Oct to 7th Oct 2001:
 - A) If you have data at 10 minute intervals, there will be 144 data points per 24 hours, so you will need to request an X Axis label every 144 points
 - B) Click ADD to show a new window. Type in Value 1 for the first point and the label 01/10/01. Click OK
 - C) Repeat for values 145 and 02/10/01, 289 for 03/10/01 etc.
 - D) Highlight any unwanted labels and click REMOVE to clear.
6. You may choose other datapoint values and labels as wished.
7. These settings need to be changed for each graph, the Save function does not apply to Chart Control properties, only to the settings chosen via the Graphing Wizard.

