



## SKYE INSTRUMENTS LIMITED

21 Ddole Enterprise Park, Llandrindod Wells, Powys, LD1 6DF UK

Tel: +44 (0) 1597 824811 Fax: +44 (0) 1597 824812

Email: [skyemail@skyeinstruments.com](mailto:skyemail@skyeinstruments.com) Web: <http://www.skyeinstruments.com>

### **SpectroSense2 Meter – Change Active Sensor Set Up**

1. Switch on the SpectroSense2 meter, wait 3 seconds until it displays the Main Menu. (If the Main Menu doesn't appear, simply press the Escape key).
2. Use the Down arrow key to choose menu option 6 and press Enter.
3. The flashing cursor in the top right hand corner should default to Active sensor number 0. If not use the Up / Down arrows to show 0 and press Enter.
4. Use the Up / Down keys to allocate the required sensor (e.g. sensor 02) under the flashing cursor. Check the sensor description is correct and press Enter
5. Use the Up / Down keys to choose the socket or i/p channel (e.g. C2) under the flashing cursor. Press Enter
6. Check the set up for Active Sensor 0 and press Enter to confirm.
7. Repeat steps 2 to 6 above for Active Sensor set up 1 and 2 and 3 as required
8. To disable a channel, allocate sensor number "--" (which is found between 15 and 00 when scrolling through) and press Enter twice. This disables the this active channel.
9. To check the set up, use the Up arrow key to choose menu option 5 and press Enter.
10. Press Escape to return to the Main Menu.