



MINIMET

Description of WizzCom Error Codes

- #5 Warning that there is some data missing within the time period selected for a graph or data summary
- #52 The program is creating a folder / directory called C:\SKYEDATA in which to store the offloaded data files
- #61 Out of memory error - hard disk or floppy disk is full, try another disk
- #62 Comm Port error. On start up WizzCom automatically chooses Comm Port 1 to use. This error shows that Comm Port 1 is in use by another program (or the mouse). Choose another Comm Port (see Chapter 3.2)
- #70 Error in writing to a file. The floppy disk may be write protected, the file may be locked, or the file may be in use by another program
- #75 Administrator Security. These setting will prevent you from downloading so need changing to allow access
- #380 Wrong font error. Choose another font, e.g. COURIER, using the Select Font button
- #8006 Comm Port error. The port you have chosen is not fitted or not available for use. Choose another Comm Port (see Chapter 3.2)
- #8010 Comm Port error. On first start up, WizzCom automatically choose Comm Port 1 to use. This error shows that Comm Port 1 is in use by another program (or the mouse). Choose another Comm Port (see Chapter 3.2)
- #8013 Comm Port error. The port you have chosen is being used by another program. Close the other program or choose another Comm Port (see Chapter 3.2)