



DATALOGGERS

Instructions to configure Logging Thresholds

1. Connect the DataHog 2 datalead to the RS232 port on the logger, and to the appropriate serial communications port on your PC.
2. Start the communications software (whichever version you are using) as usual.
3. Wake up the DataHog by pressing a key after the displayed message as usual. When the logger 'wakes up' you will see the Main Menu displayed. (Please remember that whilst the logger is 'awake' and in Main Menu mode, it is not recording any measurements.)
4. Please check your DataHog2 Hardware Configuration Certificate before you begin. This will show all the information you will be asked to enter.
To configure a channel for Threshold Logging, choose Option D from the Main Menu (by typing 'D'). Enter the Software Channel Number of the channel you wish to apply a Logging Threshold to, e.g. 00. You then need to choose the option for Normal Logging (no Thresholds), Log Above Threshold or Log Below Threshold, e.g. type 03 to choose Log Below Threshold.
Enter the Logging Threshold in the format requested - see below for examples for different channel types. The choices you have just entered will be displayed for your confirmation, however the Threshold is now expressed in the units of measurement (e.g. knots). Press 'Y' to confirm and return to the Main Menu.
5. It is advisable to check that the changes you have just made are in place before returning the DataHog 2 to logging mode.
From the Main Menu, choose Option 1 to display the current setup.
Choose '2' from the sub-menu to check the Log Mode and Thresholds. Each software channel is shown with its Log Mode and Threshold setting.
Choose '6' to return to Main Menu
6. Press ESCAPE to return the DataHog 2 to logging mode. Wait for the message 'ANY NUMERIC KEY TO WAKE UP' to appear before disconnecting the datalead and PC.

FORMAT TO ENTER THRESHOLD VALUES

1. Humidity channels - enter RH% value in the format xxx.x (e.g. 045.0 for 45%RH)
2. Temperature channels - enter the temperature value, with sign in the format +xxx.xx or -xxx.xx (e.g. +018.50 for 18.5 °C)
3. Ax+B scaled channels - the threshold must be entered as a count value with a +/- sign.
The logger's Full Scale count value is +19000.
The sensor's Full Scale empirical unit value will be shown on the logger's hardware Configuration Certificate (e.g. 3558.9 for the sensor SKE 510/I 22302)
So the number of counts per sensor unit is $+19000 / (\text{sensor Full Scale})$
(e.g. $+19000 / 3558.9 = +5.34$ for the sensor SKE 510/I 22302)
Multiply the number of counts per sensor unit by the threshold in sensor units required (to obtain the counts value at the threshold) and enter this in the format +xxxxxx or -xxxxxx
(e.g. to switch sensor SKE 510/I 22302 at a threshold of 50 watts/m², $+5.34 * 50 \text{ watt/m}^2 = 267$ - enter as +00267)
4. Windvane sensors - see Appendix 5 at the back of the logger manual for a table of Count value against wind direction degrees. Enter the value as +xxxxxx (e.g. +01621 for 45 degrees)

SKYE INSTRUMENTS LTD

21, Ddole Enterprise Park, Llandrindod Wells, Powys, LD1 6DF, UK

Tel: +44(0)1597 824811 Fax: +44(0)1597 824812

Email: skyeemail@skyeinstruments.com Web: www.skyeinstruments.com

