



# DATALOGGERS

## Wiring Details for Thermocouples



5 PIN PLUG

2 CORE SCREENED CABLE

THERMOCOUPLE TIP

Pin 1	not connected
Pin 2	not connected
Pin 3	Thermocouple
Pin 4	Thermocouple
Pin 5	Ground and cable screen



SKYE INSTRUMENTS LTD

21, Ddole Enterprise Park, Llandrindod Wells, Powys, LD1 6DF, UK

Tel: +44(0)1597 824811 Fax: +44(0)1597 824812

Email: [skyemail@skyeinstruments.com](mailto:skyemail@skyeinstruments.com) Web: [www.skyeinstruments.com](http://www.skyeinstruments.com)