



WSS2 Combined Wind Sensor Wiring Details

Below are details about how the /I DataHog2 plug is wired on the WSS2 Sensor.

- | | | |
|----|------------------|--|
| 1. | Brown | - No connection |
| 2. | Grey | - (3) Potentiometer (T1), usually excited via a resistor. |
| 3. | Green | - (1) Reed switch via 100R resistor. |
| 4. | Yellow | - (5) Wiper of potentiometer (T2), usually analogue HI. |
| 5. | White and Screen | - (2), (4) and (6), Reed switch, potentiometer (T3) usually to excitation GND. |

